

Brioche vorm exopan - anti-aanbak

Brioche mould exopan - non-stick



Nr / No	Ø cm	H cm
3515647	10	4
3515692	12	4,5
3515648	14	5
3515738	16	6,5
3515739	18	7,3
3515711	20	7,9
3515741	22	8,8
3515742	24	10

JUDGE taartvorm mini 6 stuks - anti-aanbak

Fluted round mini tart tin - non-stick



Nr / No	afm./dim. cm
3537563	4x1,5

Aspicvorm ovaal - anti-aanbak

Oval aspic mould plain bottom - non-stick



Nr / No	afm./dim. cm
3506927	7,5x5,5x3,8

Vlaaivorm geribt losse bodem - vertind

Baking tin fluted loose bottom - tin plate



Nr / No	Ø cm	H cm
3511321	20	2
3511323	24	2,5
3511325	28	2,5
3511327	32	2,5

Vlaaivorm geribt losse bodem - anti-aanbak

Baking tin fluted loose bottom - non-stick



Nr / No	Ø cm	H cm
3593084	8	1,5
3593086	10	2
3593088	12	2,5
3593090	14	2,5